

PUZZLINK


Installation Guide

Introduction

Thank you for choosing Puzzlink PVC Interlocking Floor Tiles for your flooring needs. Our interlocking floor tiles are designed for easy installation without the need for adhesives or specialised tools. This guide will provide you with step-by-step instructions on how to install these tiles and help you create a beautiful and durable floor in your space.

Tools and Materials Needed

Before you begin the installation process, make sure you have the following tools and materials ready:



Puzzlink PVC
Interlocking Floor Tiles



Rubber Mallet



Tape Measure



Stanley Knife



Straight Edge or
Chalk Line

Installation Steps

Step 1: Prepare the Room

Before you start laying the tiles, it's essential to prepare the room properly:

1. Clear the room of any furniture, debris, or obstacles.
2. Ensure that the sub floor is clean, dry, and level. If needed, make necessary repairs or use a levelling compound.

Step 2: Decide the Starting Point

Choosing the right starting point is crucial for a professional-looking installation. Here are some tips on where to begin:

- Generally, it's best to start in a corner of the room, preferably the corner that is most visible when entering the room.
- To ensure a balanced layout, measure the width of the room and find the centre point. You can use a chalk line to create a straight reference line from this centre point.
- Start laying tiles along this reference line.

Step 3: Install the First Row

1. Align the first tile with the starting point and the reference line.
2. Press the tile firmly into place.
3. Continue laying tiles in the first row, interlocking them securely. Use a mallet to gently tap the tiles into place if necessary.



Step 4: Continue Laying Tiles

1. For the second row, insert the interlocking edges of the tiles into the first row's tiles. Then, press down to interlock them.
2. Continue installing rows of tiles, making sure the interlocking edges fit snugly together.
3. If you need to cut tiles to fit around corners or obstacles, measure and mark the tiles, then use a stanley blade or jigsaw to make precise cuts.

Step 5: Complete the Installation

1. Continue laying tiles row by row until the entire room is covered.
2. When you reach the walls, you may need to trim the last row of tiles to fit. Remember to leave a small gap (around 5mm) between the tiles and the wall to account for expansion.
3. Install edging to cover the gaps along the edges and provide a finished look.

Maintenance Tips

- Regularly sweep or vacuum the floor to remove dirt and debris.
- Clean spills promptly with a damp cloth.
- For deeper cleaning, use a mild detergent and a mop.
- Avoid using abrasive cleaners or harsh chemicals.

Congratulations! You have successfully installed Puzzlink PVC Interlocking Floor Tiles in your space. Enjoy your new, easy-to-maintain and attractive flooring. If you have any questions or need further assistance, please don't hesitate to contact our customer support team.

For more information, visit our website at www.puzzlink.co.uk.

